


Shively Labs[®]

FM Broadband Multistation Broadcast Antenna

Model 6017



Instruction Manual
Installation, Operation, &
Maintenance

Congratulations!

Thank you for purchasing one of the finest FM broadcast antennas on the market today. The Shively Labs 6017 antenna is widely recognized as the top-of-the-line in its class for its superior performance and durability.

Your purchase is backed by the best technical support in the industry. Shively is a leading manufacturer in the broadcast industry, providing an extensive range of antennas, transmission line and components. Our technical staff has a wealth of experience in the broadcast industry and is standing by to serve you in any way.

This manual is intended to give you a good basic understanding of your antenna: its proper and safe installation, startup, and operation, and troubleshooting and maintenance information to keep it working satisfactorily for years to come. *Please have everyone involved with the antenna read this manual carefully, and keep it handy for future reference.*

Meanwhile, please feel free to contact your sales representative at Shively Labs at any time if you need information or help. Call or write:

Shively Labs®
a division of **Howell Laboratories, Inc.**

Bridgton, Maine 04009 USA
(207) 647-3327 1-888-SHIVELY
sales@shively.com www.shively.com
An Employee-Owned Company

24-hour (207) 329-5118
FAX (207) 647-8273
ISO 9001-Certified

Publication No. IM017 (100201)

IMPORTANT

Please read this manual in its entirety before beginning installation of your antenna!

Failure to follow the installation and operation instructions in this manual could lead to failure of your equipment and might even void your warranty!

Table of Contents

Chapter 1 Preparing for Installation	1
Receiving	1
Unpacking	1
Check the System	2
Chapter 2 Installing the Mounts	3
Before Beginning Mount Installation:	3
Mark Mount Locations on the Mounting Pole	3
Installing the Radiator Mounts on the Pole	3
Installing the 4-Way Power Divider Mounts on the Pole	4
Installing the Main Power Divider Mounts (if applicable)	6
Chapter 3 Installing the Radiators and Power Dividers	8
Before Beginning Radiator and Power Divider Installation:	8
Installing Radiators	8
Installing Power Dividers	9
Chapter 4 Installing the Coaxial Feed System	10
Before Beginning Feed System Installation:	10
Installing the Power-Divider-to-Radiator Cables	11
Installing the Main Power Divider (if applicable)	12
Installing the Main Feed Cables.....	12
Chapter 5 Pressurization and Startup	14
Before Beginning Pressurization:	14
Pressurization Procedure	14
Step 1. Leak Testing.....	14
Step 2. Purging the System.....	16
Step 3. Leaving the System Pressurized	17
Before Beginning Initial Characterization:	17
Initial Characterization (recommended)	18
Step 1. Transmission Line VSWR Reading	18
Step 2. Transmission Line TDR Reading	19
Step 3. System VSWR Reading	19
Step 4. Checking Radiator Function	19
Checkout.....	19
Chapter 6 Operation	21
Precautions	21
The Antenna.....	21
Chapter 7 Troubleshooting	22
Precautions	22
Internal Arcing.....	22
Broad Spectrum RF Noise	23
High VSWR at Startup or during Operation.....	23
Erratic VSWR	24
Change in Coverage	24
Pressure Loss or Excessive Gas Usage	24

Table of Contents (continued)

Chapter 8 Maintenance	26
Precautions.....	26
Maintenance Log.....	26
Physical Inspection.....	26
Paint	27
Troubleshooting	27
Return Policy	27
Sample Maintenance Log	28

List of Illustrations

Figure 1	Typical Mount Installation on Pole, top view.....	3
Figure 2	4-Way Power Divider Installation, top and side views.....	5
Figure 3	Main Power Divider Mount Styles.....	6
Figure 4	Radiator Installation, top view.....	9
Figure 5	Feedline Flange Detail	10
Figure 6	Flange Bolt Tightening Sequences	12
Figure 7	Pressurized Gas Schematic.....	15

List of Tables

Table 1	Minimum Bending Radii, Semiflex Coax.....	10
Table 2	Torque Specifications, Flange Bolts.....	11
Table 3	Volume of Coax per 1000 Feet of Length	17
Table 4	Troubleshooting Internal Arcing	22
Table 5	Troubleshooting High VSWR	23
Table 6	Troubleshooting Pressure Loss or Excessive Gas Usage.....	24

1 Preparing for Installation

Receiving

As soon as you receive your antenna, BEFORE signing for the shipment:

- a. Check to be sure all the material has arrived.

NOTE

The box number and the total number of boxes are marked on each box; for example, "Box 2 of 5" means "box number 2 of a total of five boxes."

- b. Check for evident damage to any of the boxes.
- c. If any boxes are missing, or if any are obviously damaged, describe the problem in a WRITTEN note on the shipping papers BEFORE signing them. Then call Shively right away, and we'll do everything we can to correct the situation.

Important!

Never store the antenna system outdoors, boxed or otherwise. Take pains to keep the antenna components dry. You will need to purge moisture from the interior of the antenna components before applying transmitter power, and purging will be much more time-consuming if the components get wet.

Unpacking

- a. Find Box 1; it is marked "Open This Box First." It contains the transformer and two copies of the installation drawing. The parts list on one sheet of the installation drawing shows what box each item is in.
- b. Then open the boxes and examine for shipping damages. File any necessary claims with the carrier immediately.
- c. If all the boxes are present and in good condition but material seems to be missing, please contact Shively Labs immediately, using the telephone or Fax number on the inside cover of this manual. For the best service, have our shop order number (S/O) handy; it's in the block at the bottom right corner of the installation drawing.
- d. Along with your antenna you will get a spare parts kit. Place this in a safe place until it is needed.

CAUTION

All contact surfaces and openings to the interior of the components are protected from contamination and from physical damage by caps and plastic bags. Do not remove this protection until ready to connect the components.

Check the System

Remember!

It is YOUR responsibility to ensure that your installation meets all applicable codes and the centerline-of-radiation requirements of your FCC construction permit.

Shively's factory designer has planned the installation of the antenna based upon information provided by you. If this information contained errors, the parts and mounting hardware will have been designed incorrectly and will cause expensive delays in installation. *Therefore, we recommend that you recheck the installation parameters during this planning stage.*

Check all the parts to be sure that they will fit the tower and each other. Study the installation drawings carefully to confirm that the information used in designing the antenna and mounts was, in fact, accurate.

Have a reliable tower person, familiar with antennas and coaxial line, inspect the tower and review the installation drawings before the full rigging crew arrives.

If design problems are found, contact Shively Labs immediately. Pay particular attention to:

- Frequency of the antenna.
- Fit of the mounts to the tower members.
- Freedom from interference by gussets, leg flanges, guys and their attachment points, tower face members, obstruction lights, and other components.
- Compatibility of transmission line and antenna input terminals.
- Location of the transmission line run relative to the antenna input terminal.
- Use of non-metallic guy sections on the tower in the region to be occupied by the FM antenna. Ensure that there are no metal guys within ten feet (three meters) of any radiator.
- Availability of proper electrical service for deicers, if applicable.
- The adequacy of the tower structure and guys to carry the windload placed upon them by the antenna.

You gave Shively this information at the time of purchase, but a last check at this time can catch an error, which will be easier to correct before installation begins.

2 Installing the Mounts

Before Beginning Mount Installation:

CAUTION

Before you begin, study the installation drawing carefully. The illustrations in this manual show typical details, but antennas vary due to pattern requirements and tower designs, so you must go by the installation drawing for the actual configuration of your antenna.

Mark Mount Locations on the Mounting Pole

- Starting at the top of the antenna, use a steel measuring tape to find the location of each mount in accordance with the installation drawing. Mark the mount locations on the pole.
- Also mark the location on the pole of any accessory mounts, such as for the power dividers or special coax line sections, to make sure they will fit as planned.
- If any problems appear during this process, please call Shively Labs and discuss them with the installation designer.

Installing the Radiator Mounts on the Pole




Figure 1. Typical Mount Installation on Pole, top view

Installing the Mounts

[Figure 1](#) is a top view showing how the radiator mount pieces fit together. Assemble and install the radiator mounts according to [Figure 1](#), your installation drawing, and the following guidelines:

- a. Find the marked locations on the mounting pole where the radiator mounts will be located.
- b. To ensure good electrical contact between the mounts and the support pole, scrape the pole paint away at the mount locations.
- c. Install the mounts as shown in [Figure 1](#) and your installation drawing.
- d. When all mounts are in place, sight along them vertically to make sure they are aligned before tightening them.
- e. Repaint the pole where you removed the paint in step b.

Installing the 4-Way Power Divider Mounts on the Pole

Assemble and install the 4-way power divider mounts according to [Figure 2](#) on page 5, your installation drawing, and the following guidelines:


- a. Find the marked locations on the mounting pole where the power divider mounts will be located.
- b. Referring to the installation drawing, mark the locations of the power divider mounts (generally there will be either two or four mounts per power divider).

CAUTION

If you don't get good electrical contact between the mounts and the pole, the antenna may not perform as designed, and may produce stray signals that will interfere with other services on the tower.

- c. To ensure good electrical contact between the mounts and the support pole, scrape the pole paint away at the power divider mount locations.
- d. Use band clamps to attach the power divider mounts loosely to the pole.
- e. When all mounts are in place, sight along them vertically to make sure they are aligned before tightening them.
- f. Repaint the pole where you removed the paint in step c.

Installing the Mounts





(not to scale)

Figure 2. 4-Way Power Divider Installation, top and side views

Installing the Main Power Divider Mounts (if applicable)

If your antenna has more than one level, a main power divider will distribute the signal among the 4-way power dividers at each antenna level. Assemble and install the main power divider mounts according to [Figure 3](#), your installation drawing, and the following guidelines:



(not to scale)

Figure 3. Main Power Divider Mount Styles

Installing the Mounts

- a. Find the marked location on the mounting pole where the power divider mounts will be located.
- b. Referring to the installation drawing, mark the locations of the power divider mounts (generally there will be two mounts).

CAUTION

If you don't get good electrical contact between the mounts and the pole, the antenna may not perform as designed, and may produce stray signals that will interfere with other services on the tower.

- c. To ensure good electrical contact between the mounts and the support pole, scrape the pole paint away at the power divider mount locations.
- d. Use band clamps to attach the power divider mounts loosely to the pole.
- e. Repaint the pole where you removed the paint in step c.

3 Installing the Radiators and Power Dividers

Before Beginning Radiator and Power Divider Installation:

CAUTION

All electrical contact surfaces and openings to the interior of the components are protected from contamination and from physical damage by plastic protectors. Do not remove the protectors until ready to connect the components.

CAUTION

The interiors of the components must be kept dry during installation. Avoid assembly during wet weather.

NOTE

Keep the plastic protectors in case you ever need to return components for repair.

CAUTION

Do not use silicone grease on an O-ring, as this will soften the silicone O-ring. Use only a light lubricating coat of petroleum jelly (provided); too much may hamper electrical contact and contaminate the interior of the system.

Be sure the O-ring is properly seated in its groove and not pinched between the flange contact surfaces.

Installing Radiators

Attach the radiators to their mounts according to [Figure 4](#) on page 9 and your installation drawing.

- a. Fit the holes in the radiator backplate over the studs on the mount.
- b. Attach the radiator to the mount, using the 3/8" hardware provided.




Figure 4. Radiator Installation, top view

Installing Power Dividers

Assemble and install the power dividers and their mounts according to your installation drawing and the following guidelines:

- Check the mount locations against your installation drawing.
- Attach the power dividers to the mounts as shown in [Figure 2](#) on page 5.
- Double-check the tightness of all components.

4 Installing the Coaxial Feed System

Before Beginning Feed System Installation:




Figure 5. Feedline Flange Detail

CAUTION

Semiflex cable has a minimum bending radius, specified by the manufacturer. Bending it too sharply will damage the cable. See [Table 1](#) for the various sizes.

Table 1. Minimum Bending Radii, Semiflex Coax

Cable Size	Radius
1/2"	5" (127 mm)
5/8"	5" (127 mm)
7/8"	10" (254 mm)
1-5/8"	20" (510 mm)

CAUTION

Stressing a coax connection after assembly can detune the system. Therefore, never make a connection and then bend or twist the cable.

Likewise, do not use the connector and flange to force the coax into shape. Form the coax to the desired shape before attaching it and align the connection properly, then make the connection.

CAUTION

Do not use silicone grease on the O-rings, as this tends to dissolve the silicone O-ring. Use only a light lubricating coat of petroleum jelly; too much may hamper electrical contact and contaminate the interior of the system.

Be very careful that each O-ring is seated in its groove and not pinched between flange contact surfaces, as this will cause a leak in the system and will be expensive to find and repair.

NOTE

Keep the hardware securing the plastic protectors. It will be used for the final connections.

Installing the Power-Divider-to-Radiator Cables

The semiflex cables have been pre-formed at the factory and marked for their respective locations. Use the markings to determine which cables go where. Install the power-divider-to-radiator flex coaxial cables as shown on the installation drawing. Follow these guidelines:

CAUTION

Be very careful to connect each power divider port to the correct radiator.

CAUTION

The specific lengths of your flex cables are required to maintain proper system phasing. Often cables will be longer than needed merely to reach the antenna inputs. This is normal and necessary.

- a. Remove the plastic protector from the coax flange. Don't lose the hardware or the O-ring.
- b. Lubricate the O-ring lightly and insert it into the groove in the coax flange.

CAUTION

Be sure each component's inner conductor fits cleanly over the mating component's inner conductor connector. If any of the fingers of the connector are forced outside the inner conductor (a "split bullet"), this will cause arcing and damage to the antenna.

- c. Use the hardware from the protective covers to attach the components. [Table 2](#) shows torque specifications for the various size flange bolts. [Figure 6](#) shows the flange bolt tightening sequence for each coax size.

[Table 2. Torque Specifications, Flange Bolts](#)

Line Size	Bolt Size	Torque	
1/2"	1/4-20	7 ft-lb	9 N-m
5/8"	1/4-20	7 ft-lb	9 N-m
7/8"	1/4-20	7 ft-lb	9 N-m
1-5/8"	5/16-18	12 ft-lb	16 N-m



Figure 6. Flange Bolt Tightening Sequences

- d. After all RF components (ie: power dividers, radiators, rigid coax) have been connected to each other, tighten the mounting bolts securing the RF feed system to the pole.

Installing the Main Power Divider (if applicable)

If your antenna has more than one level, a main power divider will feed it, with a cable to the four-way power divider at each level. Install the power divider in accordance with [Figure 3](#) on page 6 and your installation drawing.

- a. Secure the power divider to the mount saddles using the band clamps provided (generally, two clamps on a 6"-long saddle and four clamps on a 12"-long saddle).
- b. Connect the flex coax from the main power divider to the four-way power dividers at the antenna levels.

CAUTION

To prevent damage to power dividers, position the hose clamp screw housings over the saddles, not against the power dividers.

- c. As each feedline section is lifted into place, remove the plastic bags and protective covers from the flanges and install an O-ring, lubricating it with a light coat of petroleum jelly (provided with the antenna).
- d. Secure each feedline section to its mount before installing the next section.

Installing the Main Feed Cables

A main feed cable brings power from the main power divider to the four-way power divider at each level of the antenna.

CAUTION

Components are usually interchangeable and are therefore not normally match-marked in any way. Assemble any bay to any feed cable, with any mount, etc. If any matching is necessary with your system, it will be indicated on the installation drawing.

CAUTION

Be very careful to connect each power divider port to the correct radiator.

Install these cables in the same manner as the power-divider-to-radiator cables. Their mounts are similar to the four-way power divider mounts, but slightly larger to accommodate the corrugated cable outer conductor.

5 Pressurization and Startup

Before Beginning Pressurization:

Important

Shively Labs will not accept responsibility for antenna failure after operation without proper purging or positive pressure of dry air or dry nitrogen.

CAUTION

When pressurizing the system, never use a "garage" air compressor, as it will not clean the air and will blow both moisture and contaminants such as oil and graphite into the coaxial system.

Be sure to use a good quality pressure gauge which will read accurately in the 10 - 20 psig range; don't depend on the cylinder gauge, which will not be accurate at a low pressure.

Do not over-pressurize the system; it takes time for the entire system to fill with the new pressure and the pressure gauge to stabilize.

CAUTION

If all moisture is not removed from the interior of the system, it will condense when the weather cools. The condensed moisture (water) will cause arcing and permanent physical destruction of the coaxial system, including the transmitter output network.

CAUTION

You must blow dry gas *through* the system, not just maintain a pressure. The gas *volume* accomplishes the purge.

CAUTION

Never operate the antenna system without proper purging and constant positive dry gas pressure.

CAUTION

Although initial characterization is at your discretion, we strongly recommend it as the best way to identify both initial problems and possible future system damage.

Pressurization Procedure

After the antenna is installed and all lines are connected, it is necessary to check the system for leaks, purge with dry gas to remove all moisture, and leave the system pressurized with dry gas to avoid future infiltration of moisture. These steps must be taken before RF power is applied to the system.

Step 1. Leak Testing

- a. Connect a source of dry gas (cylinder nitrogen or air from a compressor-dehydrator) to the system as shown in [Figure 7](#) on page 15.
- b. Be sure to include a good quality gauge which reads accurately in the 5 - 20 psig (35 - 135 kPa) range; don't depend on the cylinder gauge, which will not be accurate enough in this pressure range.




Figure 7. Pressurized Gas Schematic

Pressure Correction:
 where PC = corrected

$$P_c = \frac{(P_R + 14.7)(T_1 + 460)}{(T_2 + 460) - 14.7}$$

final pressure, psig
 P_R = final pressure as read, psig
 T_1 = beginning temperature, degrees F.
 T_2 = final temperature, degrees F.

- c. Pressurize the system to eight (8) psig, then close the shutoff valve. Give the system one half hour to stabilize, then record the pressure and the temperature.
- d. Wait twenty-four hours, then read the pressure and the temperature again and use the formula in the sidebar to obtain a corrected pressure for comparison.
- e. If the system loses pressure at an unacceptably high rate, re-pressurize it, leaving the gas supply on. A rule of thumb is that the final pressure should not be less than half the initial pressure after twenty-four hours.

- f. Find the leak(s), using a leak detector or soap bubbles. (The most common cause of leakage is an O-ring pinched in a flange.)
- g. Correct any leaks that are found. Then repeat the leak test until the results are satisfactory.

Step 2. Purging the System

When the system is new, and any time that it has been opened, it must be purged with dry gas before operation to eliminate moisture.

The dry gas used may be dry cylinder nitrogen or air from a compressor-dehydrator. Shively Labs suggests three volume changes of dry gas for an "average" system.

There is a pressure relief valve at the top of each four-way power divider. This valve is set to open at about 10 psig. So, to purge the system, it is not necessary to send a worker to the top of the antenna to open a valve or loosen a flange. Simply raise the internal pressure enough to open the relief valve. When the purge is complete, lower the pressure and the valve will close.

Purge your system as follows:

- a. Determine how wet the system is. If a system of rigid line carefully protected from weather and assembled in dry weather is average, a system exposed to moisture during storage or installation will be relatively wet. New semi-flex transmission line, delivered pressurized with dry gas, will be relatively dry; used semi-flex will be extremely wet.

Important

Never apply transmitter power while the antenna is under vacuum.

- b. If you have any liquid water in your transformer or your transmission line, use a vacuum pump to dry the transmission line and transformer. Apply as much vacuum as you can to the system and hold the vacuum for 8 hours. This should remove any liquid water. [A vacuum pump can be rented or borrowed from a refrigeration contractor.]
- c. Determine the volume of dry gas to use for the purge.
- d. [Table 3](#) shows approximate volumes inside various coax sizes. Add the length of the antenna to the length of the transmission line to determine the overall length of the system. You may ignore the volume inside the radiators.

Table 3. Volume of Coax per 1000 Feet of Length

Coax Size	Volume
1/2"	2 cu. ft. (0.06 m ³)
5/8"	3 cu. ft. (0.08 m ³)
7/8"	4 cu. ft. (0.11 m ³)
1-5/8"	13 cu ft. (0.37 m ³)

NOTE

A standard nitrogen cylinder (9 inch diameter by 55 inches tall) contains about 200 cubic feet (2.6 m³) of gas. Shively Labs Models 1235 and 2577 compressor-dehydrators will provide about 12 cubic feet (0.34 m³) per hour; the Model 1234 about 78 cu ft (2.2 m³) per hour.

- e. Connect a source of dry gas (cylinder nitrogen or air from a compressor-dehydrator) to the system as shown in [Figure 7](#).
- f. Raise the gas pressure to 12 or 13 psig (83 - 90 kPa).
- g. If the relief valve has opened, the nitrogen cylinder will slowly drain or the compressor-dehydrator will not shut down.

Remember

It is critical to blow dry gas *through* the system, rather than merely maintain a pressure; the gas volume accomplishes the purge.

Step 3. Leaving the System Pressurized

After completion of the purge, reduce the supply pressure to about 5 to 7 psig, allowing the pressure relief valve to close and seal the system.

After the pressure has stabilized, keep careful note of cylinder pressure or compressor-dehydrator running time, to be sure that no large leaks have been overlooked. This is especially important immediately after installation or any subsequent opening and reassembly.

Before Beginning Initial Characterization:

Although initial characterization is at your discretion, we strongly recommend it as the best way to identify both initial problems and possible future system damage.

Important

In the days before the hazards of intense RF power were realized, it was common practice to have a technician climb the tower and adjust the impedance match using the transmitter as a signal source and reading the VSWR or return power on the transmitter. This practice **MUST NOT** be used, as few transmitters can be operated at a low enough power level to avoid exposing the rigger to an unsafe RF level. For reference, see 29 CFR, Section 1910.97, the OSHA standard for exposure to non-ionizing radiation.

To test and adjust VSWR safely, use low-power test equipment, such as a network analyzer or an impedance bridge. If you don't have access to low-power test equipment, please call Shively Labs before proceeding.

WARNING

Whenever a rigger is on the tower in the area of the antenna, shut off the transmitter signal and lock it off so that it cannot be turned on accidentally.

Low-power test equipment should be used to prevent excessive radiation exposure to the person doing the adjusting.

CAUTION

A high transmission line VSWR may indicate damaged transmission line and is likely to cause problems in the future, including serious damage to your equipment.

Initial Characterization (recommended)

Should any problems arise later with your antenna, it will be extremely helpful to know what the system's characteristics were when it was new. We recommend you perform the tests in this section after installation.

Step 1. Transmission Line VSWR Reading

The first step is to characterize the transmission line by itself

- a. Briefly disconnect the transmission line from the antenna system input. Seal the antenna system input to prevent the entry of moisture.
- b. Terminate the coax transmission line in an instrument-quality 50-ohm load.
- c. Measure and record the voltage standing wave ratio (VSWR). File this information with this manual for future reference.
- d. The VSWR of the transmission line should be within the manufacturer's specifications. If it is, proceed. If not, you should call the manufacturer before connecting the antenna. Problems must be worked out with the design engineer on a case-by-case basis.

Step 2. Transmission Line TDR Reading

With the transmission line still terminated in 50 ohms, make a time domain reflectometer (TDR) plot. Label and file the plot with this manual.

Step 3. System VSWR Reading

You tested the VSWR of the transmission line alone. Now test the VSWR of the system as a whole.

- a. Remove the load and connect the transmission line to the transformer input, with an O-ring to seal the connection.
- b. Repeat the purge process after sealing the line, in accordance with [Purging the System](#) on page 16.
- c. Measure VSWR. VSWR at this point should be below 1.2 : 1.
- d. Record the reading and file it with this manual.

If VSWR is not satisfactory, check to be sure all the radiators are functioning (see below). If they are, call Shively Labs to help identify the problem.

Step 4. Checking Radiator Function

Again using the low-power test equipment to provide a signal to the antenna and read VSWR, have the rigger detune each radiator in turn. The simplest way to detune a radiator is to short across the "wings" or dipole arms, for instance with a screwdriver or wrench.

Each time, a deflection in VSWR should be apparent. The deflection for various bays should be similar, but not necessarily identical.

If the VSWR of the array does not change when a radiator is detuned, that bay is not functioning. Check to be sure the radiator was installed properly, including the inner conductor connector.

If you cannot find the problem, please call Shively Labs before proceeding.

Checkout

Before beginning checkout of the antenna system, be sure the following items have been done:

- The antenna system has been installed in accordance with this manual and the installation drawing.
- All radiators are operating and VSWR is within specification.
- The initial characterization data have been recorded.
- The system is gas-tight and purged.

Check the system out as follows:

- a. Bring up RF power slowly and observe transmitter readings, stability, and general operation.
- b. Run at about half power for at least an hour, reading forward and reflected power, stability, etc.

Pressurization and Startup

- c. If the system is stable and seems to be operating properly, bring it up to full power. Take initial readings, and repeat the readings periodically.

Performance readings should not change, and there should be no evidence of heating in the antenna system.

If any problem is found, fix it now. Call Shively Labs if you need help or advice.

6 Operation

Precautions

The broadcast industry has recently recognized the potential medical hazards of intense radio frequency radiation. Don't expose personnel to personal harm. For reference, see CFR 29, Section 1910.97, the OSHA standard for exposure to non-ionizing radiation.

WARNING

Whenever a rigger is on the tower in the area of the antenna, shut off the transmitter and lock it off so that it cannot be turned on accidentally.

CAUTION

Never operate the antenna system without proper purging and constant positive dry gas pressure. Shively Labs will not accept responsibility for antenna failure after operation without proper purging or positive pressure of dry air or dry nitrogen.

The Antenna

Once the antenna has been installed and tested according to this manual, simply apply the transmitter signal. Don't exceed the rated power capacity of the antenna.

To obtain the best performance and dependability from your Shively Labs antenna, read and follow the "maintenance" section of this manual.

7 Troubleshooting

Precautions

WARNING

Troubleshooting should be performed only by personnel experienced in RF systems and familiar with this equipment.

WARNING

The broadcast industry has recently recognized the potential medical hazards of intense radio frequency radiation. Don't expose personnel to personal harm. For reference, see CFR 29, Section 1910.97, the OSHA standard for exposure to non-ionizing radiation. Whenever a rigger is on the tower in the area of the antenna, shut off the transmitter and lock it off so that it cannot be turned on accidentally.

CAUTION

Whenever you have the system open for repair, you must purge it again as described in [Purging the System](#) on page 16. Never begin operating the system under power until you are sure all the moisture has been purged from it. You can do permanent damage to the entire system, including the transmitter.

CAUTION

VSWR does not change of its own accord. If you find you must repeatedly readjust the transformer to correct the VSWR, find and correct the problem quickly. Otherwise, you will almost certainly burn up your antenna and damage your transmitter. Look for the cause in the following table.

Internal Arcing

Look for the cause of internal arcing in [Table 4](#).

Table 4. Troubleshooting Internal Arcing

Possible Causes:	Cures:
Physical damage to transmission line, feedline, or radiators. Damage may have been caused by ice, lightning, tower work, or many other factors.	Locate the damage. Replace damaged components.
Damage may cause arcing directly or by allowing water inside the system.	Purge the system after repair, in accordance with Purging the System on page 16.
Missing or misaligned O-ring, if the system has been opened recently.	Locate the O-ring leak, using soap solution. Replace the O-ring if damaged.
Loss of pressurization.	Locate the leak. Re-purge in accordance with Purging the System on page 16 and restore pressurization.

Broad Spectrum RF Noise

This indicates that some metal components are not in good electrical contact with the tower. First, check your antenna mounts, then other tower components, to be sure that the tower paint has been scraped away and that all mounting hardware is tight.

Any metal part in poor contact with the tower will constitute a non-linear junction and cast a broad-spectrum signal. This includes antennas, transmission line, mounts, ladders, and other electrical components.

High VSWR at Startup or during Operation

(may interfere with other services on the tower)

High VSWR (Voltage Standing Wave Ratio) is caused by any factor which changes the impedance match between the transmitter and the antenna system.

Look for the cause in [Table 5](#).

Table 5. Troubleshooting High VSWR

Possible Causes:	Cures:
Wrong antenna for the application and frequency. Occasionally a customer provides wrong data to Shively or buys a used antenna designed for another application.	Contact your sales representative at Shively Labs.
Split bullet in the transmission line or in the baymount (see Figure 5 on page 10). A split bullet is an inner conductor connector misaligned such that one or more of its contact arms is stuck outside the conductor instead of inside. (A missing bullet will cause infinite VSWR.)	Replace the inner conductor connector. It may also be necessary to replace the inner conductor section if it has been damaged.
Mismatched assembly of the antenna. The assembly must be exactly as shown in the installation drawing.	Reassemble according to the installation drawing.
Radiators out of sequence (especially on a null-filled or half-wave-spaced system).	Assemble the antenna exactly as shown in the installation drawing and as marked.
Components of other services have entered the RF field (later installations or broken components).	Remove broken components. Rearrange tower components as necessary to correct the VSWR problem.
Physical damage to the cables, power dividers, or radiators. This may be from ice, lightning, tower work, or any other source.	Replace damaged components.

Table 5. Troubleshooting High VSWR (continued)

Possible Causes:	Cures:
Paint has been applied to the radiators, possibly during a recent tower painting.	Remove the paint from the radiators.

Erratic VSWR

If VSWR readings fluctuate, then either there is residual water in the system, or system components are damaged.

Follow this sequence of actions:

- a. Repeat the purging process as described in [Purging the System](#) on page 16.
- b. Test impedance again.
- c. If purging does not correct the situation, you may have liquid water in your transmission line. Use a vacuum pump to dry the transmission line. [A vacuum pump can be rented or borrowed from a refrigeration contractor.]
- d. Hold as much vacuum as you can for 24 hours, then check VSWR again.
- e. If VSWR is still erratic, contact Shively Labs.

Change in Coverage

Changes in broadcast coverage may be caused by the same factors that produce VSWR changes. If coverage seems to have changed, look for VSWR changes and troubleshoot in accordance with [High VSWR at Startup or during Operation](#) on page 23.

It is important to recognize, however, that apparent changes in coverage may be due to subjective factors or faults of the receiving equipment. Before doing more than checking the VSWR, be sure that an actual coverage change has occurred.

Pressure Loss or Excessive Gas Usage

If your system will not hold pressure as described in [Leak Testing](#) on page 14, look for the cause in [Table 6](#).

Table 6. Troubleshooting Pressure Loss or Excessive Gas Usage

Possible Causes:	Cures:
O-ring missing or poorly installed in transmission line, feedline, or baymount flange.	Find the leaky O-ring using soap solution. Replace the O-ring.
Loose connecting hardware between components.	Tighten loose connections when found.

Troubleshooting

Table 6. Troubleshooting Pressure Loss or Excessive Gas Usage

Possible Causes:	Cures:
Mechanical damage to cables, power dividers, or radiators. Check for leaks using soap solution.	Replace damaged components.

8 Maintenance

Precautions

WARNING

Maintenance should be performed only by personnel experienced in RF systems and familiar with this equipment.

WARNING

The broadcast industry has recently recognized the potential medical hazards of intense radio frequency radiation. Don't expose personnel to personal harm. For reference, see CFR 29, Section 1910.97, the OSHA standard for exposure to non-ionizing radiation. Whenever a rigger is on the tower in the area of the antenna, shut off the transmitter and lock it off so that it cannot be turned on accidentally.

CAUTION

When you have had the system open for repair, you must purge it again as described in [Purging the System](#) on page 16. Never begin operating the system under power until you are sure all the moisture has been purged from it. You can do permanent damage to the entire system, including the transmitter.

CAUTION

When removing or replacing radiators on the tower, never let the weight of the radiator hang on the cable. This will damage the connector and possibly the inner conductor. Support the weight of the radiator until the mount bolts are tightened.

CAUTION

Do not use silicone grease on an O-ring, as this will soften the silicone O-ring. Use only a light lubricating coat of petroleum jelly (provided); too much may hamper electrical contact and contaminate the interior of the system.

Be sure the O-ring is properly seated in its groove and not pinched between the flange contact surfaces.

Maintenance Log

Shively recommends that you keep a maintenance log; in it record performance parameters such as readings of VSWR.

Such a log can be invaluable in spotting and identifying problems. [Sample Maintenance Log](#) on page 28 shows a suggested log form you may use if you like.

Physical Inspection

The antenna system should operate for years with no problem. However, any time you have a rigger up on the tower, it's a good idea to have him check for general condition, looseness of components, and electrical damage. During this inspection, all mounting, flange-connection, and electrical hardware should be tightened.

Keep an eye on dry gas usage. A sudden increase in usage indicates a leak in the system. Troubleshoot per [Chapter 7](#).

Paint

The radiators should never be painted (a coating of paint affects VSWR), and they need no surface protection, since they are made of stainless. This includes Teflon or other "ice-prevention" coatings.

It is not necessary to paint the coax and power dividers, although no harm will result from doing so.

Troubleshooting

Troubleshoot the antenna system as described in [Chapter 7](#).

Return Policy

When returning any material to the factory, be sure to call your salesman and obtain an authorized return (AR) number first. Use this number in all correspondence. This number helps us to track your returned item. It will expedite repair or replacement and prevent loss of your material.

Sample
Maintenance Log

DATE	VSWR	GAS PRESS	OBSERVATIONS Visual Inspection of Antenna, Obstruction Lighting; Hardware Checked; Tower Repairs Accomplished; etc.